

⚠ Qalitrack Manned only. This guide covers Qalitrack Manned. Qalitrack Unmanned has its own installation guide.

DEPLOYMENT FOLDER CONTENTS

<code>install.bat</code>	Double-click to install the backend
<code>install.ps1</code>	Called automatically by <code>install.bat</code>
<code>docker-compose.yml</code>	Backend service definitions
<code>.env</code>	Secrets file — provided by the Qalitrack team
<code>QalitrackHardware.exe</code>	Hardware client installer (weighbridge, camera, RFID/NFC)
<code>QalitrackFrontend.exe</code>	Frontend desktop app installer

PREREQUISITES

Docker Desktop and WSL2 are installed automatically by the script. If a restart is required mid-install the script will tell you — restart the PC and double-click `install.bat` again.

PART 1 — BACKEND SERVICES

- 1 Confirm Docker Desktop is running (whale icon in the taskbar).
- 2 Place the `.env` file provided for this site in the same folder as `install.bat`.
- 3 Double-click **install.bat** and click **Yes** on the UAC prompt. The script installs WSL2 and Docker Desktop if missing, clones the source, builds all images, and starts every service. *First run: 5–15 minutes.*
- 4 When the green banner appears, verify in a browser:

Service	URL
Gateway	<code>http://localhost:7000</code>
User Service	<code>http://localhost:7001</code>
Master Data	<code>http://localhost:7002</code>
Backup	<code>http://localhost:7003</code>
Transactions	<code>http://localhost:7004</code>

The backend restarts automatically after every reboot — no action needed.

PART 2 — HARDWARE CLIENT

Collects weighbridge data, camera feed, RFID and NFC reads.

- 1 Right-click **QalitrackHardware.exe** → *Run as administrator*.
- 2 Fill in the setup wizard:
 - Weighbridge** — TCP (IP + port, default 3002) or Serial (COM port + baud rate)
 - Camera** — IP, RTSP port 554, path, username/password
 - RFID** — tick if installed, enter IP + port (2022)
 - NFC** — tick if installed, select COM port
- 3 Click **Install Service**. Starts automatically, survives reboots.
- 4 Verify at `http://localhost:5000`.

Update: run the new exe as Administrator — wizard pre-fills existing config, button reads *Update & Reinstall*.

PART 3 — FRONTEND

The Qalitrack web application desktop client.

- 1 Double-click **QalitrackFrontend.exe**.
- 2 Follow the on-screen steps and accept the defaults.
- 3 Launch from the desktop shortcut created by the installer.

Update: run the new `QalitrackFrontend.exe` — upgrades in place.

TROUBLESHOOTING

Symptom	Fix
install.bat says "restart required"	Restart the PC then double-click <code>install.bat</code> again. Happens once when WSL2 or Docker Desktop installs for the first time.
Docker not running	Open Docker Desktop, wait for the whale icon to be solid, re-run <code>install.bat</code> .
.env not found	Place <code>.env</code> in the same folder as <code>install.bat</code> and re-run.
WSL not installed	Run <code>wsl --install</code> in PowerShell as Administrator, restart, re-run <code>install.bat</code> .
Services unhealthy	Wait 60 s — databases take time on first boot. Recheck the URLs.
Hardware: Installation Failed	Must run <code>QalitrackHardware.exe</code> as Administrator.
Weighbridge no data (TCP)	Confirm IP and port. Test: <code>ping <ip></code> in PowerShell.
Weighbridge no data (Serial)	Confirm COM port in Device Manager. Check baud rate against weighbridge manual.
Camera not connecting	Test in VLC: <code>rtsp://user:pass@ip:554/path</code> . Service retries automatically.

UPDATING THE BACKEND

Re-run `install.bat` — pulls latest code and rebuilds. Existing data is preserved.